
MIDIECIAC: G72CC



Instructions for Use

Gebrauchsanleitung

PHILIPS




ENGLISH

VIDEOPAC GAME COMPUTER G7200

The G7200 Videopac Game Computer you have just acquired is a complete and self-contained video game computer with full alphanumeric keyboard, two multi-directional hand-controls with action-button and a black and white monitor with loudspeaker. Your G7200 will accept all Videopac cartridges, including the Videopac Chess module C 7010.

The G7200 offers the advantage of completely independent Videopac pleasure, since it does not require a separate (colour) TV.




- 1. 9" black and white monitor
- 2. Videopac game cartridge (not included)
- 3. Slot for game cartridge
- 4. On/Off switch
- 5. Special Videopac contrast control
- Volume control
- 7. Alphanumeric keyboard
- 8. Connections for hand-controls
- 9. Hand-control


- Multi-directional joystick
- 11. Action-button
- Brightness control
- 13. Loudspeaker
- 14. Mains flex
- 15. DIN output socket
- Slots for mounting C7010 Videopac Chess module

PREPARING TO PLAY VIDEOPAC


- Connect your Videopac G7200 game computer to mains supply. (In the UK, the set is supplied without mains plug)
- Connect hand-controls to sockets in the recess below the keyboard.



- Insert a Videopac cartridge in game computer.
- Switch on game computer by pushing power switch (inwards from left to right).




- Press RESET (A) and the text "SELECT GAME" (,,Départ") will appear on your screen.
- Set brightness control at required level.



Set volume control at required level.



Set contrast control at required level. When using one of the Videopac cartridges, numbered 1 to 43, see page 6 for proper adjustment of contrast control. For cartridges numbered higher than 43, see instructions for use received with the cartridge.



For further instructions on how to play the game, see the instructions for use of the cartridge you have selected.

The special Philips Videopac Contrast Control




All Videopac game cartridges are designed to produce images in colour. The G7200 game computer will not produce pictures in colour. This will not present a problem however. since the game computer is equipped with a special contrast control. It will allow you to make the necessary adjustments in black and white to distinguish all essential symbols.

The G7200 contrast control has seven basic positions. making it possible to actually reverse the contrast effect as indicated by the following images for Videopac cartridge 1:







Contrast control in position 7.


Contrast control in position 4. Contrast control in position 1.

In the table you will find instructions for the best adjustment of the contrast control for Videopac cartridges numbered 1 to 43. For cartridges carrying a higher number, refer to the instructions for use you receive with those cartridges.

Using the G7200 in combination with a colour TV set

in the rear of the game computer you will find an eight-pin OIN output socket. When you have a colour TV with e SCART-connection, you may be able to connect your Videopac game. computer to your TV set and thus produce images in colour We advise you to consult your dealer first





Pin number DIN plug	Signal		Corresponding SCART pin	
1	Status RGB	3V-75 Ohm	16	
2	Eerth		4	
3	BLUE in	0.7V 75 Ohm	7	
4	SYNC	0,3V-75 Ohm	20	
5	RED in	0.7V 75 Ohm	15	
8	Status CVBS	12V 10 kQhm	8	
7	SOUNOin	0.2 V eff 1 kOhm	2-6	
8	GREENIN	0,7V 75 Ohm	11	


_		_			
VIDEOPAC CARTRIDGE NUMBER	1	S	Race, Spin-out and Cryptogram	4	5
ā	2	Ē	Pairs, Space Rendezvous and Logic	8	4/5
₹	3	Σ	American Football		2 or 6
2	4	1	Air-Sea War and Battle	<u> </u>	4
	5	15	Blackjack	3 8	4
5	6	ž	Tenpin Bowling and Basketball	- 1	4
9	7	2	Mathematician and Echo	₹ 1	4
	8	ดี	Baseball	(≥	2
4	9	ы	Computer Programmer	3 2	4
3	10	ō	Golf	O	2 or 6
,	11 %	T.	Cosmic Conflict		4
ַ	12	F	Take the Money and Run	7	4
5	13	F	Playschool Math		4
4	14	5	Gunfighter	ী	4
1	15	CONTAINS THE FOLLOWING GAME(S)	Samurai	POSITION OF CONTRAST CONTRO	5
1	16	E	Depth Charge and Marksman	150	4
	17	M	Chinese Logic	S	4
	18	8	LaserWar		5
	19		Catch the Ball and Noughts and Crosses		2 or 4
	20		Stone Sling		4
	21		Secret of the Pharaohs		4
П	22		Space Monster		4
	23		Las Vegas Gambling		4
	24		Flipper Game		4
	25		Skiling (Slalom, Giant Slalom, Down Hill)		5
	26		Basket Game	711	4
	27		Electronic Table Football		4
	28		Electronic Volleyball		4
	29		Dam Buster	4	4
	30		Battlefield	7	6
	31		Musician		
	32		Labyrinth Game and Supermind		4
	33		Jumping Acrobats		4
	34		Satellite Attack	1	6
	35		Electronic Billiards (Eight Ball and Rotation)		6
П	36		Electronic Soccer and Electronic Ice Hockey		6
ı	37		Monkeyshines	-86	4
u	38		Munchkin	-	2
	39		Freedom Fighters		2
	40		4 in 1 Row		1
	41		Conquest of the World		7
	42		Quest for the Rings		6
	43	Ш	Pickaxe Pete		1
	C7010		Chess module		1
	A		Newscaster		7

DEUTSCH

MIDEOPAC SPIELCOMPUTER G7200

Der Videopac-Spielcomputer G 7200, dessen glücklicher Besitzer Sie gerade geworden sind, ist ein kompletter, in sich abgeschlossener Video-Spielcomputer mit vollständiger alphanumerischer Tastatur und zwei Handreglern mit Aktionstasten sowie einem Schwarzweiss-Monitor mit Lautsprecher. Ihr G 7200 kann mit allen Videopac-Kassetten einschliesslich Videopac-Schachmodul C 7010, programmiert werden.

Der G 7200 bietet das völlig unabhängige Videopac-Vergnügen, da er nicht auf ein separates (Farb-)TV-Gerät angewiesen ist.




- 9-Zoll-Schwarzweissmonitor Videopac-Spielkassette (nicht
 - ingebriffen)
- Einschuböffnung für Spielkassette
- 4. Ein Aus-Schalter
- 5. Videopac-Spezialkontraststeuerung
- Lautstärkeregler
- 7. Alphanumerische Tastatur
- 8. Anschlüsse für Handregler

- 9. Handregler
- Steuerknüppel
- Aktionstaste
- Helligkeitsregler
- Lautsprecher
- 14. Netzkabel
- 15. OIN-Ausgangsbuchse
- Einschuböffnungen für Videopac-Schachmodul C 7010

ANSCHLUSS UND EINSTELLUNGEN VOR DEM SPIEL


Schliessen Sie Ihren Videopac-Spielcomputer G 7200 an das Stromnetz an.

Schliessen Sie die Handregler an den Buchsen in der Bodenvertiefung des Computers an,



Schieben Sie eine Videopac-Kassette in den Spielcomputer.

Schalten Sie den Spielcomputer ein, indem Sie den Hauptschalter drücken (nach innen von linksnach rechts).



Drücken Sie RESET (△). Auf Ihrem Bildschirm erscheint der Text "SELECT GAME".

Regeln Sie die Helligkeit auf den gewünschten Wert.



Regeln Sie die Lautstärke auf den gewünschten Wert.




Regeln Sie den Kontrast auf den gewünschten Wert. Falls Sie eine der Videopac-Kassetten Nr. 1 bis 43 verwenden, nehmen Sie die richtige Kontrasteinstellung wie auf Seite 10 beschrieben vor. Die Kontrastregelung für Kassetten ab Nr. 44 ist in den einzelnen Gebrauchsanleitungen beschrieben.



9

Die Anweisungen für die jeweiligen Spiele finden Sie in der Gebrauchsanleitung der gewählten Kassette.

Die Videopac-Spezialkontraststeuerung von Philips




Alle Videopac Kassetten erzeugen farbige Bilder; der Bildschirm des Spielcomputers G 7200 zeigt jedoch ein schwarz-weisses Bild. Allerdings entstehen daraus keine Nachteile, denn der Spielcomputer verfügt über einen speziellen Kontrastregler. Damit können Sie das Schwarzweissbild so einstellen, dass alle wichtigen Symbole leicht zu unterscheiden sind.

Der Kontrastregler des G 7200 hat sieben Grundpositionen, mit denen sogar der Kontrasteffekt umgekehrt werden kann, wie die folgenden Bilder aus Videopac-Kassette 1 zeigen:








Kontrastregler in Position 7. Kontrastregler in Position 4. Kontrastregler in Position 1.

In der untenstehenden Tabelle finden Sie die korrekte Kontrastreglerposition für die Videopac-Kassetten Nr. 1 bis 43. Bei Kassetten mit höheren Nummern ist die korrekte Einstellung in der mitgelieferten Gebrauchsanleitung angegeben.

Verwendung des G 7200 zusammen mit einem Farb-TV-Gerät

An der Rückseite des Spielcompulers belindet sich eine 8- polige DIN-Ausgangsbuchse. Wenn ihr Farb TV-Gerat über einen SCART-Anschluss verfügt, können Sie wahrscheinlich hiren Videopec Spielcomputer an das Geral anschliessen und das Kassettenbild in Farbe reproduzieren Erkundigen Sie sich bei ihrem Fachhändler über diese Anschlüssmöglichkeil



Staft Nir	Signal	Entspr SCART-Stift		
1	Status RGB	3V 75 D	16	
2	Erde		4	
3	BLAUein	0,7V 75Ω	7	
4	SYNC	0,3V-75Ω	20	
5	ROTem	0,7V 75 Ω	15	
6	Status CVBS	12V 10 kΩ	В	
7	TONein	0,2V eff 1 kΩ	2-6	
8	GRUNein	0,7V 75 Ω	11	

2	1	110	Autorennen, Wirbelwind und Gehelmschrift	4.	5
Ž	2	SPIELE	Memory, Rendezvous im Weltall und Knobeln	3	4/5
5	3	100	Rugby	9	2/6
巴	4		See- und Luftkrieg, und Panzerschlacht	Ç	4
E	5	8	Black Jack	P.	4
5	6	ā	Bowling und Basketball	5	4
AS	7	ত	Der kleine Mathematikus und Pass auf	2	4
×	8	₹	Baseball	E	2
Ç	9	ž	Computerprogrammierung		4
اچ	10	I	Golf	X	2/6
VIDEOPAC KASSETTEN-NR	11 4	BEZEICHNUNG DER	Krieg im Weltall	STELLUNG DES KONTRASTREGLERS	4
١٥	12	Z	Das Millionenspiel	a	4
\mathbf{z}	13	BE	Vorschul-Rechnen	G	4
Ш	14		Revolverhelden	3	4
	15		Samurai	7	5
Ш	16		Schützenfest und Schiffeversenken	딥	4
	17		Chinesische Logik	5	4
	18		Laser-Krieg		5
ш	19		Fang den Ball und Drei mat drei		2/4
ш	20		Burgenschlacht		4
-	21		Das Geheimnis der Pharaonen		4
	22		Das Weltraum-Monster		4
	23		Einarmiger Bandit		4
	24		Flipper		4
	25		Ski-rennen Ski-rennen		5
ш	26		Korbball		4
ш	27		Tischfussball		4
ш	28		Elektronischer Volleyball		4
	29		Dămme sprengen		4
ш	30		Schlachtfelt		6
ш	31		Musiker		7
ш	32		Labyrinth und Superhirn		4
ш	33		Kunstspringer		4
ш	34		Satellitten-Angriff		6
ш	35		Elektronisches Billard		5-6
1119	36		Elektronisch Fussball und Elektronisch Eishockey		5-6
	37		Affenjagd		4
	38		Mampfer		6
	39		Freiheitskämpfer im Weltraum		2
	40		4 Gewinnt		1
	41		Eroberung der Welt		7
	C 7010		Die Suche nach den Ringen		6
	A .				7
	A		Laufschrift		1